KitchenAid®

COOKTOP PARTS

For Model: KERC600GWH1, KERC600GAL1, KERC600GBS1
(White) (Almond) (Black-Stainless)

30" Free-Standing
DESIGNER STYLE



1		Cooktop, Ceran
	9751752	White
	9751753	Almond
	9751754	Black
2	9780939	Gasket, Cooktop
	9781614	Gasket, Cooktop
3	9751478	Gasket, Console
4	9781459	Rod, Large Element
5	9781548	Support, Element
6	9751629	Bracket, Pivot
	9780265	Screw
7	9781553	Brace, Support
8	9750821	Clip, Support (4)
9	9750969	Bumper, Rubber
10	9781497	Hot Light
11		Element, Surface
	8053604	1500W - LR
	8053606	1800W - RF
	9753475	2500W - LF
12	3149333	Screw
13	9780265	Screw
14	8053605	2500W - RR
15	9781460	Rod, Small Element
16	9751871	Screw
17	341196	Thermo Disc
18	9751800	Cover, Vent
19	9751841	Gasket, Vent Cover
20		Backsplash
	9751266GW	White
	9751266GT	Almond
	9751266GB	Black
21	9751984	Bimetal
22		Limiter, Temp.
	8053620	LR-RF-RR
	3191988	LF
23	9780272	Screw
24	9750273	Receptacle, Light
25	422581	Lamp. Flourescent
26	9751664	Cover, Backsplash
27		Endcap, Backsplash
	9751268FW	White (Right)
	9751268FT	Almond (Right)
	9751268FB	Black (Right)
	9751267FW	White (Left)
	9751267FT	Almond (Left)
	9751267FB	Black (Left)
	3149333	Screw (4)
28		Cover, Light
	9751327	White
	9751633	Almond
	9751632	Black
29	9781118	Starter
30		Trim, Cooktop
	9751275PW	White (Right)
	9751275PT	Almond (Right)
	9751275PB	Black (Right)
	9751276PW	White (Left)

	9751276PT	Almond (Left)
	9751276PB	Black (Left)
31	9750866	Holder, Starter
32		Glass, Backsplash
	9781154	(White)
	9753292	(Black)
33	9753291	Panel, Backguard (Stainless)
34	98997	Clip, Wire

DOOR AND DRAWER PARTS

For Model: KERC600GWH1, KERC600GAL1, KERC600GBS1
(White) (Almond) (Black-Stainless)



1	9750676	Retainer, Glass
2		Trim, Door-Left
	9750631PW	White
	9750631PT	Almond
	9750631PB	Black
3		Trim, Door-Right
	9750632PW	White
	9750632PT	Almond
	9750632PB	Black
4		Trim, Door Bottom
	9781209PW	White
	9781209PT	Almond
	9781209PB	Black
	9780265	Screw, 10 x 3/8
5		Glass, Door
	9781627PW	White
	9781627PT	Almond
	9753378	Black
6		Vent, Door
	9753498GW	White
	9753498GT	Almond
	9753498GB	Black (Assy w/SS Panel)
	9781659	Gasket, Door Vent
	9781490	Seal, Door Vent Side
8		Handle, Door
	9780523PW	White
	9780523PT	Almond
	9780523PB	Black
9	9781449	Gasket, Door Glass
10	9750234	Hinge, Door R or L
11	9781592	Baffle, Glass
12	9781602	Frame, Window
13	9781586	Shield Door
14	9780771	Bumper, Rubber
15	9781593	Glass, Pyro Door
16	9781587	Seal, Glass
18	9781626	Insulation
19	9781600GM	Liner, Door
20		Drawer & Roller
	9780583	For White & Almond
	9750257	For Black-SS
21	9750169	Bracket, Drawer
22	9750693	Heat, Channel
24		Front, Drawer
	9750168PW	White
	9750168PT	Almond
	9750569PB	Black
	9780265	Screw (2)
25	423713	Support, Roller
27	90296	Clip
28	9781502	Retainer, Glass(8)
	9780265	Screw (8)
29	9780265	Screw
30	9780272	Screw
31	9781072	Screw
33	9781771	Deflector, Steam (For Black-SS)
34	9750614PB	Trim, Drawer-Top

35	9753329	Spacer
36	9753293	Panel, Drawer (Stainless)
37	9750613PB	Trim, Drawer-Btm

OVEN CHASSIS PARTS

For Model: KERC600GWH1, KERC600GAL1, KERC600GBS1
(White) (Almond) (Black-Stainless)



1	9751350	Vent Box, Oven
2	9750514GM	Chassis, Front
3	9750222	Insulation, Wrap
4	9750221	Insulation, Rear
5	9781293GM	Oven Liner
6	3191649	Gasket Oven
7		Oven, Side L or R
	9750148PW	White
	9750148PT	Almond
	9750148PB	Black
8	9781447	Shield, Insulation
9	9751789	Fan Duct, Side
11	9752637	Burner Box
12	9750142	Oven Bottom
13	9751653	Duct, Top
14	9751060	Support, Fan
15	9750223	Drawer Rail, Left
	9750224	Drawer Rail, Right
16	9751020	Motor, Fan
17	9750147	Bottom Rail (2)
18	312701	Foot, (4)
19	9750149	Hinge, Door L or R
20	421771	Support Rail, Pan
25	9753091	Vent, Tube
29	9781581	Door Switch
30	9751948	Relay, Dlb.
31	9780578	Button, Plug
32	9753413	Block, Balance
33	9752654	Insulation, Side
34	9751808	Screw

OVEN PARTS

For Model: KERC600GWH1, KERC600GAL1, KERC600GBS1
(White) (Almond) (Black-Stainless)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

1	9750967	Element, Broil
2	9750213	Element, Bake
	9781509	Screw (4)
15	8935	Bulb, Oven Light
16	9781050	Socket, Oven Light
17	340184	Screw
18	420104GM	Grill, Broiler
19	420101GM	Pan, Broiler
20	9781509	Screw
21	9750498	Rack, Standard
22	8053344	Sensor
	9781509	Screw
23	3184533	Gasket, Lens
24	9781049	Lens, Oven Light

REAR CHASSIS PARTS

For Model: KERC600GWH1, KERC600GAL1, KERC600GBS1
(White) (Almond) (Black-Stainless)



1	9751051	Back panel,Chassis
2	9752344	Box, Terminal
3	9751353	Panel, Rear Cover
4	9752345	Cover, Terminal Box
5	9751418	Bracket, Lock
6	9780265	Screw
7	9751439	Oven Lock Assembly
8	9751590	Solenoid
9	422222	Screw
10	424238	Nut
12	9751763	Switch, Interloc
13	9750887	Screw
14	9750888	Nut
15	9750523	Rod, Lock
16	3191044	Ballast, Light
	424238	Washer
17	258076	Terminal Block
18	3169573	Ground Strap
	313660	Clip, (1)
19	9751798	Vent Back, Oven
20	112432	Nut
21	690989	Screw, Grounding
22	98884	Screw
23	423247	Screw
24	340184	Screw

CONTROL PANEL PARTS

For Model: KERC600GWH1, KERC600GAL1, KERC600GBS1
(White) (Almond) (Black-Stainless)



1		Console, Glass
	9752356CW	White
	9752356CT	Almond
	9751899	Black
	9781488	Spacer
	420719	Washer
2	3191107	Timer, Electronic
3	9780271	Screw, 8-18 x 1/4"
4		End Cap (Right Hand)
	9751280FW	White
	9751280FT	Almond
	9751280FB	Black
		End Cap (Left Hand)
	9751279FW	White
	9751279FT	Almond
	9751279FB	Black
5	9780265	Screw
8		Knobs, Control
	9750372FW	White
	9750372FT	Almond
	9750372FF	Black
21		Switch, Infinite
	9751364	1250-1500W, LR
	9751363	1700W, RF
	9751362	2100-2600W, LF
	9751758	Dual Element, RR
22		Nut, Mounting
	422617	Single Element
	9751711	Dual Element
23	9781455	Seal, Switch (4)

Following Parts Not Illustrated

SPLICING WIRES--25FT. LENGTH

242828	Wire, Black 12 Ga. 150~c
242820	Wire, Black 14 Ga. 150~c
242821	Wire, Blue 14 Ga. 150~c
242822	Wire, Brown 14 Ga. 150~c
242830	Wire, Brown 14 Ga. 200~c
242823	Wire, Green 14 Ga. 150~c
242824	Wire, Orange 14 Ga. 150~c
242829	Wire, Red 12 Ga. 150~c
242825	Wire, Red 14 Ga. 150~c
242831	Wire, Red 14 Ga. 200~c
242826	Wire, White 14 Ga. 150~c
242827	Wire, Yellow 14 Ga. 150~c
242832	Wire, Yellow 14 Ga. 200~c

PAINT, TOUCH-UP (1/2oz.)

72017	White
72107	Almond
72109	New Avocado
72108	Coffee
72110	Harvest Gold
72112	Toast
72113	Platinum
511873	**White Porcelain (2 Oz.)

**Note: Cooktop Surface is Porcelain; All Other Panels are Painted Surfaces.

PAINT, PRESSURIZED SPRAY (13 oz.)

350930	White
350956	Almond
261888	New Avocado
261886	Coffee
261890	Harvest Gold
285365	Toast
285366	Platinum
285006	Superior Black
206922	Primer (White)

PAINT, BULK (1 qt.)

799344	White (Uncut)
978883	Almond (Uncut)
261891	Harvest Gold (Uncut)
285367	Toast (Uncut)
285368	Platinum (Uncut)

REFINISHING MATERIAL

799832	Kit, Porcelain Repair (White)
242756	Touch-Up Self-Clean (1/2 Pt.)

INSULATION

9750222	Insulation, Wrap
9750221	Insulation, Rear

CLEANER, COOKTOP

9780196	Glass Cleaner
3183488	Scraper

ACCESSORIES

241430	Foil, Aluminum Oven (18" X 25')

LUBRICANT

261582	Grease

ANTI-TIP KIT

9751745	Anti-Tip Kit

LITERATURE PARTS

LIT9752043	Installation Instructions
LIT9753311	Use & Care Guide
LIT9753027	Tech Sheet
LIT9753028	Wiring Diagram
LIT9752686	Smart & Easy Guide
LIT3191638	Tips, Safety Cook
LIT9752775	Template, Anti-Tip

WIRING HARNESS PARTS

9753382	Harness, Wire (Main Harness)
9781757	Harness, Wire (Main Harness) (For BS Model)
9781822	Harness, Wire (Cooktop)
9781769	Harness, Wire (Front Console)
9750376	Harness, Wire (Oven Door)

9781767	Harness, Wire (Ceran)
9781655	L2 - Electric
20082084	Tie, Wire
9751750	Harness, Wire (Top Light)
690989	Screw, Ground
3196520	Clip, Wire
9751868	Grommet, Harness